



Let's get started. [Open for step-by-step setup instructions.](#)



Your sound, your way with the VIZIO Mobile App

The VIZIO Mobile App and VIZIO Account required for control of advanced soundbar and microphone functionality, settings, and to receive system updates. Scan to download.



1. Plug in the soundbar. Stand near the soundbar and activate Bluetooth® on your mobile device.
2. Open the VIZIO Mobile App to pair and connect to the soundbar. The app automatically recognizes your soundbar for the first hour after installation.
3. If pairing after the first hour, ensure the soundbar is powered on with a quick press of the Volume (+) button on the soundbar. Press and hold the soundbar Bluetooth (⌘) button for 5 seconds and release to initiate the pairing process for up to 3 minutes. The soundbar blue LED light will blink slowly.
4. Once paired, you can adjust audio levels, microphone functions and enable Bluetooth music streaming in the app.



If you do not have a smart phone, your TV remote will also control soundbar volume, mute, and unmute.

Discover custom MicMe settings using the VIZIO Mobile App

Explore advanced settings


Explore advanced soundbar and microphone settings such as bass, treble, ClearDialog, Ambient Light settings, and more.

Customization

Use Voice Enhancements to punch up your vocals, or adjust Echo Effect, Mic Volume, and all soundbar audio to your preference.

Management

Manage soundbar audio with your TV remote control or VIZIO Mobile App. If preferred, a soundbar remote control can be purchased on vizio.com




Exclusive for VIZIO TV

Simplified setup and control for VIZIO TV owners.

Audio Control Menu

Press the Settings button  on your VIZIO TV remote and select ALL SETTINGS > AUDIO to get started.



VIZIO QuickFit

A proprietary mounting solution that enables elegant, tool-free installation of your soundbar with compatible VIZIO TVs using the included mounting screws.

Learn more at vizio.com/quickfit



Need more help?

Scan for additional support and documentation.

Get to know your soundbar

Using Bluetooth to stream music

1. Select the MicMe SB device in the VIZIO Mobile App, then press the Bluetooth button.
2. Press "Play Music". The blue LED will blink rapidly and a tone will play twice to indicate the soundbar is in pairing mode.
3. Go to Bluetooth settings in your mobile device, select VIZIO MicMe SB and pair.
4. The blue LED will stop blinking and a confirmation tone will play when you have successfully paired.

You are all set. Now you can begin streaming your favorite music, podcasts and more.

Note: If you do not have the VIZIO Mobile App, you can quickly press and release the Bluetooth button on the soundbar. Then follow steps 3 and 4.










Understanding HDMI® ARC/eARC

MicMe features HDMI eARC for the highest quality audio formats like full-bandwidth Dolby Atmos audio when watching TV. For optimal audio performance, be sure to connect the included HDMI cable to your TV's HDMI ARC or HDMI eARC port.



No TV HDMI port? Contact VIZIO support at support.vizio.com if your TV requires optical connection.

Soundbar LED light guide


-  **White**
Power indicator
-  **Magenta**
HDMI input
-  **Dark Blue**
Bluetooth input
-  **Dark Blue Flashing**
Bluetooth pairing mode
-  **Light + Dark Blue Flashing**
Bluetooth pairing mode for mics
-  **Orange**
USB input
-  **Green**
Dolby Atmos® content is detected
-  **Yellow**
DTS:X® content is detected
-  **Orange + Green Flashing**
Firmware is being updated


Unfold for a simple 1-2-3 setup.



1 Charge


Plug in docking station and insert microphones as shown to charge.




 The mics will display the current battery level when placed in the charging dock.

2 Plug In


Insert and plug in power cables to the soundbar and subwoofer. Now you can download the VIZIO Mobile app to your mobile device.




 A sound will play when the soundbar powers on for the first time and the front white LED light will turn on.

3 Connect to your TV

Connect the soundbar to the HDMI ARC or eARC port on your TV with the included HDMI cable.



 For optimal audio, ensure that HDMI CEC and eARC are turned on in your TV settings menu. Refer to your TV user guide for details.


4 Start Singing

Sing with your TV

Once your soundbar is connected to your TV, launch your favorite music app and pick up a mic to start singing.


Stream from your phone

Use Bluetooth to stream music directly to MicMe. Refer to the *Get to know your Soundbar* section for detailed instructions.




MicMe works with all popular apps

Not sure where to find karaoke music? Here are a few suggestions:

 Access over 85,000 karaoke songs by downloading the free MicMe Karaoke by Stingray app for your iOS or Android device.


- Launch your favorite music or karaoke app from your phone and stream via Bluetooth.
- Go into a music app, such as Apple Music. Select Lyrics and click on the microphone to remove original vocals and start your performance.
- Other highly rated karaoke apps: Stingray Karaoke, Smule, Yokee Karaoke, and Starmaker.
- Open an app from your smart TV, such as Stingray Karaoke, Kanto Karaoke, Party Tyme Karaoke, or YouTube (check out Sing King).

Some music and karaoke apps require a user account or subscription.

 Have questions? We're here to help. Contact VIZIO support at support.vizio.com

Microphone Settings

Settings can be accessed with the microphone mode button and adjusted using the +/- . These can also be adjusted in the VIZIO Mobile App, along with additional features.



Microphone Volume

Press 1x: Adjust microphone sensitivity.

Echo Effect

Press 2x: Adjust echo intensity of your voice.

Ambient Light

Press 3x: Select your favorite color.

Get to know your MicMe microphones

Microphone Basics

Fully charged mics have up to 8 hours of battery life.

After 10 minutes of no use, mics will go into Sleep mode, and will auto power off after 30 minutes. Place mics back in the charging dock when not in use.

When powered on, mics will display a greeting, identity of *MIC 1* or *MIC 2*, and battery life percentage.

If your mics become disconnected, press and hold the power button on the bottom of each mic for 2 seconds to power off, then press and hold again for 2 seconds to power on. If your mics do not connect or are not connecting refer to the online User's Manual.

Only two mics can be paired to the soundbar at a time. MicMe microphones are only compatible with VIZIO MicMe.

For optimal performance, sing into the top of the mic, not into the grey fabric side.

Refer to the online User's Manual for mic care instructions.

Model: SK210X-0805

